


LA-F2 User Manual and Program Version Cross-Reference Table

Method to Check the Program Version



STEP1:Press and hold the .

STEP2:Press the to enter the Information Interface.

STEP3:Display the program version in the bottom right corner of the

Program Version	User Manual
V2.0.2~V2.1.5.F	LA-F2 V2.0 User Manual Rev00(program version:V2.0.2~V2.1.5.F)

* Explanation:

Machine Model + Mechanical Version + User Manual + Manual Version (Program Version)

